

AIR FRYER





AF-101

FEATURES

- Digital Control with 9 Pre-Set Recipes
- Voltage: 220-240V, 50/60Hz
- Fry Pot and Rack, Dishwasher Safe
- Time Control: 0-30 minutes or 0-60 minutes
- Temperature Control: 80-200
- Cool-Touch Handle
- Double Protection Circuits
- Overheat Protection
- Non-Slip Feet
- Micro Switch Control for Safe Monitoring of the Fryer and Food at Anytime



AF-102

FEATURES

- Type: DH-601AW
- Digital Control with 9 Pre-Set Recipes
- Voltage: 220-240V, 50/60Hz
- Fry Pot and Rack, Dishwasher Safe
- Time Control: 0-30 minutes or 0-60 minutes
- Temperature Control: 80-200°C
- Cool-Touch Handle
- Double Protection Circuits
- Overheat Protection
- Non-Slip Feet
- Micro Switch Control for Safe Monitoring of the Fryer and Food at Anytime



AF-103

FEATURES

- Type: DH-601AW with Windows
- Voltage: 220-240V, 50/60Hz
- No Power Cord
- Digital Control with 9 Pre-Set Recipes
- Fry Pot and Rack, Dishwasher Safe
- Time Control: 0-30 minutes or 0-60 minutes
- Temperature Control: 80-200°C
- Cool-Touch Handle
- Double Protection Circuits
- Overheat Protection
- Non-Slip Feet
- Micro Switch Control for Safe Monitoring of the Fryer and Food at Anytime



AF-104

FEATURES

- Type: DH-628A
- Digital Control with 9 Pre-Set Recipes
- Voltage: 220-240V, 50/60Hz
- Fry Pot and Rack, Dishwasher Safe
- Time Control: 0-30 minutes or 0-60 minutes
- Temperature Control: 80-200°C
- Cool-Touch Handle
- Double Protection Circuits
- Overheat Protection
- Non-Slip Feet
- Micro Switch Control for Safe Monitoring of the Fryer and Food at Anytime



AF-105

FEATURES

- Type: DH601AW with Windows
- Digital Control with 9 Pre-Set Recipes
- Voltage: 220-240V, 50/60Hz
- Fry Pot and Rack, Dishwasher Safe
- Time Control: 0-30 minutes or 0-60 minutes
- Temperature Control: 80-200°C
- Cool-Touch Handle
- Double Protection Circuits
- Overheat Protection
- Non-Slip Feet
- Micro Switch Control for Safe Monitoring of the Fryer and Food at Anytime